


A


Paper Airplane Glider

B


ASSEMBLY




FOLD A TO A, B TO B




FOLD C TO C, D TO D



FOLD IN HALF MAKING SURE THE OTHER FOLDS ARE ON THE INSIDE




FOLD DOWN ONE WING, THEN THE OTHER



HOW TO LAUNCH

Hold glider with thumb and forefinger where indicated. ★
 To achieve maximum performance, throw the nose pointed up slightly and release with full arm extension (follow through). It is not necessary to throw with great force. Adjust for dives and stalls as shown.



Bend tail down if nose goes up and glider stalls.
 Bend tail up if nose goes down and glider dives.

